HCR Series - Removable Bare Tube Bundle Shell & Tube

The HCR Series is a unique design allowing the tube bundle to be removed for cleaning or exchange while the shell remains mounted and shell connections remain undisturbed. By only replacing the tube bundle portion of the cooler it will cut down on labor and saving on cost of replacing a complete cooler allowing for quicker pay-back.

The HCR is based off of the HC 1200 and 1700. All performance for heat rejection and pressure drop are the same.



How to Order

Model Series



(+Shell Maximum Pressure Rating is 150 psi) ** 2000 series sizes are only HCRA, not available with other port configurations.

HCR - NPT Shell Side Connections x NPT Tube Side Connections

HCRS - SAE ORB Shell Side Connections x NPT Tube Side Connections



1224, 1236, 1248, 1724, 1736, 1748

(See Performance Curve Chart on page 3 for sizes or XSelector®* sizing program)

(Baffle spacing is dependent on applicable sizes found in sizing charts on

page 3 or can be determined by using XSelector®* sizing program)

HCRF - SAE Code 61 Flanges on Shell Side (UNC Threads) x NPT Tube Side Connections HCRA+ ** - 150# ASME RF Flanges on Shell Side x NPT Tube Side Connections.

Baffle Spacing







Tubeside Passes

0 - One Pass T - Two Pass

Replacement Bundle Assemblies

		D (1)			
Model Code	Size	Baffle Spacing	24	36	48
HCR-12**-2.5-*	1200	2.5	52893	52895	52897
HCR-12**-6-*	1200	6	52894	52896	52898
HCR-17**-3.5-*	1700	3.5	52901	52903	52905
HCR-17**-8.4-*	1700	8.4	52902	52904	52906

2.5, 3.5, 6, 8.4

6 - 3/8"

Features

1200/1700 Interchangeable with TTP HC and C Series

Multiple Connection Options

- NPT x NPT
 150# ASME RF Flanges x NPT
- SAE x NPT
- SAE Code 61 x NPT

End Bonnets Removable for Servicing

Mounting Feet Included (May be rotated)

Materials

Tubes Copper Tubesheet Carbon Steel Shell Carbon Steel Baffles Carbon Steel End Bonnets Cast Iron Mounting Brackets Carbon Steel Gaskets Nitrile Rubber/Cellulose Fiber Nameplate Aluminum Foil

Ratings

Maximum Operating Pressure - Shell Side 300 PSI

Maximum Operating Pressure - Tube Side 150 PSI

Maximum Operating Temperature 300°F

Selection Procedure

Performance Curves are based on 100SSU oil leaving the cooler 40°F higher than the incoming water temperature (40°F approach temperature). Curves are based on a 2:1 oil to water ratio.

STEP 1 Determine the Heat Load. This will vary with different systems, but typically coolers are sized to remove 25 to 50% of the input nameplate horsepower. (Example: 100 HP Power Unit x .33 = 33 HP Heat load.) If BTU/HR is known: HP = $\frac{BTU/HR}{2545}$

STEP 2 Determine Approach Temperature.

Desired oil leaving cooler $^{\circ}F$ – Water Inlet temp. $^{\circ}F$ = Actual Approach

STEP 3 Determine Curve Horsepower Heat Load. Enter the information from above:

HP heat load x $\frac{40}{\text{Actual Approach}}$ x $\frac{\text{Viscosity}}{\text{Correction A}} = \frac{\text{Curve}}{\text{Horsepower}}$

- **STEP 4 Enter curves** at oil flow through cooler and curve horsepower. Any curve above the intersecting point will work.
- **STEP 5 Determine Oil Pressure Drop from Curves.** Multiply pressure drop from curve by correction factor B found on oil viscosity correction curve.

• = 5 PSI = 10 PSI \blacktriangle = 20 PSI

Oil Temperature

Oil coolers can be selected by using entering or leaving oil tempertures.

Typical operating temperature ranges are:

Hydraulic Motor Oil	110°F - 130°F
Hydrostatic Drive Oil	130°F - 180°F
Lube Oil Circuits	110°F - 130°F
Automatic Transmission Fluid	200°F - 300°F

Desired Reservoir Temperature

Return Line Cooling: Desired temperature is the oil temperature leaving the cooler. This will be the same temperature that will be found in the reservoir.

Off-Line Recirculation Cooling Loop: Desired temperature is the temperature entering the cooler. In this case, the oil temperature change must be determined so that the actual oil leaving temperature can be found. Calculate the oil temperature change (Oil **#**T) with this formula:

Oil #T=(BTUs/HR)/GPM Oil Flow x 210).


To calculate the oil leaving temperature from the cooler, use this formula:

Oil Leaving Temperature = Oil Entering Temperature - Oil #T.

This formula may also be used in any application where the only temperature available is the entering oil temperature.

Oil Pressure Drop: Most systems can tolerate a pressure drop through the heat exchanger of 20 to 30 PSI. Excessive pressure drop should be avoided. Care should be taken to limit pressure drop to 5 PSI or less for case drain applications where high back pressure may damage the pump shaft seals.

Viscosity Correction




Maximum Flow Rates

Example Model No. HC - 1024 - 2 - 6 - F						
•	V			•		
Unit	Baffle	Shell Side	Т	ube Side (GPN	I)	
Size	Spacing	(GPM)	0	Т	F	
1200	2.5, 6	60, 115	224	112	56	
1700	3.5, 8.4	125, 253	465	232	116	

Exceptions to Maximum Shell Side Flows						
HC-1724-3.5-6-*	105 GPM Max.					
HC-1724-8.4-6-*	200 GPM Max.					

Caution: Incorrect installation can cause this product to fail prematurely, causing the shell side and tube side fluids to intermix.


Piping Diagram



Specific applications may have different piping arrangements. Contact factory for assistance.

Performance Curves

HCR-1200/1700




Curve Number	Model	Shipping Weight (LBS)
1	HCR-1224-2.5-6-T	85
2	HCR-1224-6-6-T	85
3	HCR-1236-2.5-6-T	110
4	HCR-1236-6-6-T	110
5	HCR-1248-2.5-6-T	135
6	HCR-1248-6-6-T	135
7	HCR-1736-3.5-6-T	180
8	HCR-1736-8.4-6-T	180
9	HCR-1748-3.5-6-T	220
10	HCR-1748-8.4-6-T	220

Shipping weights are approximate.


Dimensions

One Pass



												L							
Model	A	В	C	D	Е	F	G	н	J	К	NPT/ BSPP	SAE	м	N	Р	R NPT	S NPT	U (HCRF)	V (HCRA)
1224	6.26	7.75	18.25	4.06	14.14	4.80	8.00	3.25	.62x.88	3/8	2	-32 - 2 ½-12	31.75	6.38	8.43	1/2 (4)	3	4.88	5.88
1236	6.26	7.75	30.25	4.06	26.14	4.80	8.00	3.25	.62x.88	3/8	2	-32 - 2 ½-12	43.75	6.38	8.43	1/2 (4)	3	4.88	5.88
1248	6.26	7.75	42.25	4.06	38.14	4.80	8.00	3.25	.62x.88	3/8	2	-32 - 2 ½-12	55.75	6.38	8.43	1/2 (4)	3	4.88	5.88
1724	8.62	10.50	17.00	5.43	12.00	7.31	10.50	4.25	0.69	3/8	3	-32 - 2 ½-12	34.10	8.16	10.66	1/2 (4)	4	6.82	7.25
1736	8.62	10.50	29.00	5.43	24.00	7.31	10.50	4.25	0.69	3/8	3	-32 - 2 ½-12	46.10	8.16	10.66	1/2 (4)	4	6.82	7.25
1748	8.62	10.50	41.00	5.43	36.00	7.31	10.50	4.25	0.69	3/8	3	-32 - 2 ½-12	58.10	8.16	10.66	1/2 (4)	4	6.82	7.25


HCRF Code 61 Flange



4 Bolt Flange

Series	Flange Size	GG	НН	Z
HCR-1200	2	1.69	3.06	1/2-13 UNC
HCR-1700	3	2.44	4.19	5/8-11 UNC

HCRA 150 # ASME Flange




150# Flange

Series	Flange Size	BC	N
HCR-1200	2	4.75	4
HCR-1700	3	6	4


Dimensions

Two Pass



												L								
Model	A	в	C	D	Е	F	G	н	J	К	NPT/ BSPP	SAE	м	N	Р	R NPT	S NPT	т	U (HCRF)	V (HCRA)
1224	6.26	7.75	18.25	4.06	14.14	4.80	8.00	3.25	.62x.88	3/8	2	-32 - 2 ½-12	31.06	5.94	8.00	1/2 (4)	2	1.56	4.88	5.88
1236	6.26	7.75	30.25	4.06	26.14	4.80	8.00	3.25	.62x.88	3/8	2	-32 - 2 ½-12	43.06	5.94	8.00	1/2 (4)	2	1.56	4.88	5.88
1248	6.26	7.75	42.25	4.06	38.14	4.80	8.00	3.25	.62x.88	3/8	2	-32 - 2 ½-12	55.06	5.94	8.00	1/2 (4)	2	1.56	4.88	5.88
1724	8.62	10.50	17.00	5.43	12.00	7.31	10.50	4.25	0.69	3/8	3	-32 - 2 ½-12	33.05	7.98	10.48	1/2 (4)	2 1/2	2.25	6.82	7.25
1736	8.62	10.50	29.00	5.43	24.00	7.31	10.50	4.25	0.69	3/8	3	-32 - 2 ½-12	45.05	7.98	10.48	1/2 (4)	2 1/2	2.25	6.82	7.25
1748	8.62	10.50	41.00	5.43	36.00	7.31	10.50	4.25	0.69	3/8	3	-32 - 2 ½-12	57.05	7.98	10.48	1/2 (4)	2 1/2	2.25	6.82	7.25


HCRF Code 61 Flange



4 Bolt Flange

Series	Flange Size	GG	НН	z
HCR-1200	2	1.69	3.06	1/2-13 UNC
HCR-1700	3	2.44	4.19	5/8-11 UNC

HCRA 150 # ASME Flange



150# Flange

Series	Flange Size	BC	N
HCR-1200	2	4.75	4
HCR-1700	3	6	4